NETWORK CAMERA

TC2

User manual

NETWORK CAMERA TC2

Model :	TC2
Dimensions :	44x24x44mm
Network :	WiFi 2.4G
IEEE standard :	802.11b/g/n
Power interface :	Micro USB
Power input :	3.7~4.2V
Working temperature :	-20°C~70°C

Light Status

When the Camera is powered on:

- Blue Flash: Ready status, can be added by the APP;
- Blue low-speed flashing: The network is not working, please check the network;
- Solid blue: indicates normal working state;
- Solid red: indicates power access;

Pair the Gateway with APP

1 Open the APP   **2** Touch the "☰" icon on the top left of the screen

APP

3 Select [**Camera**]


4 Select[**Add camera**]


Camera

Camera1
Camera2

Add Camera

**5** Follow the prompts to activate the device, and then tap [**Next**]

- 1.Ensure the device is connected to power andturned on(Press the ON/OFF button for 2 seconds).
- 2.Ensure the device enters the fast flashing bluelight state (press the reset button for 5 seconds).
- 3. Ensure the distance between the phone and thedevice is within 3 meters.

Add camera

Next

Reset button

6 press"➕" sign

Nearby device

PPSCA900130

PPSCA900130A20

PPSCA900130A0C

7 Disposition，Select the network and input your WiFi password

Configure Network

WIFI
WiFi Password
Camera name

OK

Configure Network

WIFI
WiFi Password

Cancel Choose a network
✓ TTLOCK
mywifi
sciener-x

*5G is not supported.Please select a WiFi of 2.4G

⚠ Notice: If the above process times out, Please press the reset button for 5 seconds and try again.

Limited Warranty

1. For any defect in material and workmanship, the original purchaser of the product can:
   1) Return or ask for a replacement within 7 invoice days.
   2) Ask for a replacement within 15 invoice days.
   3) Ask for free repair in 365 invoice days.
2. This warranty does not cover defects caused by modification, alteration, misuse or physical abuse of the product.